LUMEN FOCUS FFRP 14 T8 INSTALL KIT

WARNING - RISK OF FIRE OR ELECTRIC SHOCK.
INSTALL THIS KIT ONLY IN LUMINAIRES THAT HAVE THE
CONSTRUCTION FEATURES AND DIMENSIONS SHOWN IN THE
PHOTOGRAPHS AND / OR DRAWINGS AND WHERE THE INPUT
RATING OF THE RETROFIT KITS DOES NOT EXCEED THE INPUT
RATING OF THE LUMINAIRE.

WARNING - TO PREVENT WIRING DAMAGE OR ABRASION, DO NOT EXPOSE WIRING TO EDGES OF SHEET METAL OR OTHER SHARP OBJECTS.

WARNING - RISK OF FIRE OR ELECTRIC SHOCK.

LUMINAIRE WIRING AND ELECTRICAL PARTS MAY BE DAMAGED

WHEN DRILLING FOR INSTALLATION OF LED RETROFIT KIT. CHECK

FOR ENCLOSED WIRING AND COMPONENTS.



STEP 1 TURN OFF POWER REMOVE DOOR FROM LUMINAIRE



STEP 2 REMOVE LAMPS (RECYCLE LAMPS)



STEP 3 REMOVE BALLAST COVER



STEP 4 REMOVE BALLAST SOCKET BARS AND ANY WIRING FROM THE LUMINAIRE FOR UP LIGHT LUMINAIRE INSTALL

FOR UP LIGHT LUMINAIRE INSTALI UP LIGHT COVERS (2) 1 FOR EACH SIDE WITH (2) TEK SCREWS PER COVER

INSTALL KIT TO FIT 48" X 9.750" LUMINAIRE

CAUTION: DO NOT MAKE OR ALTER ANY OPEN HOLES IN THE ENCLOSURE OF WIRING OR ELECTRICAL COMPONENTS DURING KIT INSTALL.

WARNING - RISK OF FIRE, ELECTRIC SHOCK, OR PERSONAL INJURY. BEFORE INSTALLATION TURN POWER OFF.

WARNING - RISK OF FIRE OR ELECTRIC SHOCK, LED RETROFIT KIT INSTALLATION REQUIRES KNOWLEDGE OF LUMINAIRES ELECTRICAL SYSTEMS. IF NOT QUALIFIED DO NOT ATTEMPT INSTALLATION. CONTACT A

LINE NO.

01

QUALIFIED ELECTRICIAN.



STEP 5 HANG THE FFRP14WRAPT8
USING THE SLOTS THAT WERE USED
FOR THE DOOR HINGS OR LATCHES

CONNECT POWER TO THE DRIVER USING QUICK DISCONNECT PROVIDED IN THE KIT.

INSTALL SAFETY TETHER AT EACH END OF THE LUMINAIRE. USING TEK SCREWS SUPPLIED IN THE KIT.

INSTALL GROUND LEAD TO LUMINAIRE USING TEK SCREW AND WASHER



STEP 6 SWING FFRP14WRAPT8 AND SECURE TO THE FIXTURE FITING THE FFRP14WRAP AROUND THE FIXTURE



PARTS LIST FOR FFLP14 KIT

QTY

1

SAFETY-KEYS

WIRE SCHEMATIC

Line side input to driver

120V to 277V and all voltages in between 120V - 277V input

PART NAME

FFRP14WRAPT8

STEP 7 INSTALL LENS, INSTALL SAFETY KEYS IN THE (4) SLOTS ON THE BACK OF THE FFRP14WRAP. TURN POWER BACK ON TO THE

LUMINAIRE



WHEN INSTALLING KIT
MAINTAIN EXISTING GROUNI
ON THE FIXTURE

DRIVER





